



An installation schematic showing how to install the MultiTimer, the ChloriMate, the pH-Mate, and the PoolMate controllers and dosing pumps and solenoid valves.



46 Bryant Road **P** +64 7 849 7185
PO Box 10333 **F** 0800 725 673
Hamilton, New Zealand **w** sclnz.co.nz

This schematic is not to scale and is for illustration purposes only. Please read the rules below.

Installation rules:

1. Fit the probe after the filter but before the heater.
2. Never run the probe wire anywhere near an electrical cable.
3. Fit the injection fittings after the last piece of equipment. Chemicals must never be injected prior to a heater or a heat exchanger.
4. Do not install any dosing devices directly above the chemical containers.
5. The arrows denote the water flow direction.

